

3535 Factoria Blvd. SE Suite 100 Bellevue, WA 98006 Phone: (425) 882-2206 Fax: (425) 867-0865 www.data-linc.com

SRM6100-SLC Manual Addendum Instructions for Allen-Bradley SLC Chassis Mount Serial Radio Modem

The Allen-Bradley SLC rack mount version of the SRM6100 radio modem is functionally identical to the SRM6100 stand-alone version. However, there is one minor difference in the layout. Please note the following:

The configuration button is located below the RS232 port of the unit. The switch is accessed through the small hole labeled "CONFIG."

A minimum clearance of three inches needs to be provided between the front of the modem (when installed in rack) and anything that would reside in front of the modem (I.E. a panel door, etc...).

Technical Support

If further information is needed, please call Technical Support at (425) 882-2206 or email support@data-linc.com.